


# Service Manual Trucks

Group **37**

Electrical Schematic:  
Interior Cab Lamps (front)

VNL, VNM


From Build Date 2.98




PV776-370-98221/2

**VOLVO**

BATTERY 12 VOLT  
 IGNITION 12 VOLT  
 ACCESSORY 12 VOLT



W/O POWER WINDOWS	WITH POWER WINDOWS	W/O CENTRAL DOOR LOCK	WITH CENTRAL DOOR LOCK
<p>OC</p> <p>10 C</p> <p>OC-L</p> <p>11 E</p> <p>SPLICE PACK OG</p> <p>11 A</p> <p>OG</p> <p>LHS GROUND STUD #22 INTERIOR SIDE</p>	<p>OC-A</p> <p>TO POWER WINDOWS SCHEMATIC</p>	<p>OC</p> <p>12 C</p> <p>OC-R</p> <p>13 B</p> <p>SPLICE PACK O</p> <p>13 A</p> <p>OG</p> <p>RHS GROUND STUD #19 INTERIOR SIDE</p>	<p>OC-A</p> <p>TO CENTRAL DOOR LOCK SCHEMATIC</p>
GROUND DETAIL A		GROUND DETAIL B	


















**Interior Cab Lamps (front) - VNL, VNM**

LHS GROUND STUD #22 INTERIOR SIDE






EFFECTIVE DATE	DESCRIPTION
4/98	CORRECTED MISC

CONNECTOR AND SPLICE INFORMATION  
CONNECTORS VIEWED FROM CABLE ENTRY



 <p><b>CONNECTOR 1 CAB TO OVERHEAD LAMPS</b></p> <table border="1"> <thead> <tr> <th colspan="3">TABLE OF CONTENTS</th> </tr> <tr> <th>CAVITY</th> <th>CIRCUIT</th> <th>FUNCTION</th> </tr> </thead> <tbody> <tr> <td>B</td> <td>131/503</td> <td>12 VOLT SUPPLY</td> </tr> <tr> <td>C</td> <td>505</td> <td>12 VOLT SUPPLY</td> </tr> <tr> <td>F</td> <td>OC-S</td> <td>GROUND</td> </tr> </tbody> </table>	TABLE OF CONTENTS			CAVITY	CIRCUIT	FUNCTION	B	131/503	12 VOLT SUPPLY	C	505	12 VOLT SUPPLY	F	OC-S	GROUND	 <p><b>CONNECTOR 7 LEFT SIDE DOOR LAMP</b></p> <table border="1"> <thead> <tr> <th colspan="3">TABLE OF CONTENTS</th> </tr> <tr> <th>CAVITY</th> <th>CIRCUIT</th> <th>FUNCTION</th> </tr> </thead> <tbody> <tr> <td>A</td> <td>501</td> <td>12 VOLT SUPPLY</td> </tr> <tr> <td>B</td> <td>500L</td> <td>GROUND</td> </tr> <tr> <td>C</td> <td>OC</td> <td>GROUND</td> </tr> </tbody> </table>	TABLE OF CONTENTS			CAVITY	CIRCUIT	FUNCTION	A	501	12 VOLT SUPPLY	B	500L	GROUND	C	OC	GROUND															
TABLE OF CONTENTS																																														
CAVITY	CIRCUIT	FUNCTION																																												
B	131/503	12 VOLT SUPPLY																																												
C	505	12 VOLT SUPPLY																																												
F	OC-S	GROUND																																												
TABLE OF CONTENTS																																														
CAVITY	CIRCUIT	FUNCTION																																												
A	501	12 VOLT SUPPLY																																												
B	500L	GROUND																																												
C	OC	GROUND																																												
 <p><b>CONNECTOR 2 CAB HARNESS TO RHS DOOR HARNESS</b></p> <table border="1"> <thead> <tr> <th colspan="3">TABLE OF CONTENTS</th> </tr> <tr> <th>CAVITY</th> <th>CIRCUIT</th> <th>FUNCTION</th> </tr> </thead> <tbody> <tr> <td>A</td> <td>501</td> <td>12 VOLT SUPPLY</td> </tr> <tr> <td>B</td> <td>500R</td> <td>GROUND RHS DOOR</td> </tr> </tbody> </table>	TABLE OF CONTENTS			CAVITY	CIRCUIT	FUNCTION	A	501	12 VOLT SUPPLY	B	500R	GROUND RHS DOOR	 <p><b>CONNECTOR 8 RIGHT SIDE DOOR LAMP</b></p> <table border="1"> <thead> <tr> <th colspan="3">TABLE OF CONTENTS</th> </tr> <tr> <th>CAVITY</th> <th>CIRCUIT</th> <th>FUNCTION</th> </tr> </thead> <tbody> <tr> <td>A</td> <td>501</td> <td>12 VOLT SUPPLY</td> </tr> <tr> <td>B</td> <td>500R</td> <td>GROUND</td> </tr> <tr> <td>C</td> <td>OC</td> <td>GROUND</td> </tr> </tbody> </table>	TABLE OF CONTENTS			CAVITY	CIRCUIT	FUNCTION	A	501	12 VOLT SUPPLY	B	500R	GROUND	C	OC	GROUND																		
TABLE OF CONTENTS																																														
CAVITY	CIRCUIT	FUNCTION																																												
A	501	12 VOLT SUPPLY																																												
B	500R	GROUND RHS DOOR																																												
TABLE OF CONTENTS																																														
CAVITY	CIRCUIT	FUNCTION																																												
A	501	12 VOLT SUPPLY																																												
B	500R	GROUND																																												
C	OC	GROUND																																												
 <p><b>CONNECTOR 3 CAB HARNESS TO LHS DOOR HARNESS</b></p> <table border="1"> <thead> <tr> <th colspan="3">TABLE OF CONTENTS</th> </tr> <tr> <th>CAVITY</th> <th>CIRCUIT</th> <th>FUNCTION</th> </tr> </thead> <tbody> <tr> <td>A</td> <td>501</td> <td>12 VOLT SUPPLY</td> </tr> <tr> <td>B</td> <td>500L</td> <td>GROUND RHS DOOR</td> </tr> </tbody> </table>	TABLE OF CONTENTS			CAVITY	CIRCUIT	FUNCTION	A	501	12 VOLT SUPPLY	B	500L	GROUND RHS DOOR	 <p><b>CONNECTOR 9 SPLICE PACK OG</b></p> <table border="1"> <thead> <tr> <th colspan="3">TABLE OF CONTENTS</th> </tr> <tr> <th>CAVITY</th> <th>CIRCUIT</th> <th>FUNCTION</th> </tr> </thead> <tbody> <tr> <td>A</td> <td>OG</td> <td>GROUND</td> </tr> <tr> <td>J</td> <td>OC-S</td> <td>GROUND CAB LAMP</td> </tr> </tbody> </table>	TABLE OF CONTENTS			CAVITY	CIRCUIT	FUNCTION	A	OG	GROUND	J	OC-S	GROUND CAB LAMP																					
TABLE OF CONTENTS																																														
CAVITY	CIRCUIT	FUNCTION																																												
A	501	12 VOLT SUPPLY																																												
B	500L	GROUND RHS DOOR																																												
TABLE OF CONTENTS																																														
CAVITY	CIRCUIT	FUNCTION																																												
A	OG	GROUND																																												
J	OC-S	GROUND CAB LAMP																																												
 <p><b>CONNECTOR 4 COURTESY DOOR LAMP RELAY R10</b></p> <table border="1"> <thead> <tr> <th colspan="3">TABLE OF CONTENTS</th> </tr> <tr> <th>CAVITY</th> <th>CIRCUIT</th> <th>FUNCTION</th> </tr> </thead> <tbody> <tr> <td>86</td> <td>503</td> <td>12 VOLT SUPPLY</td> </tr> <tr> <td>85</td> <td>504L/504R</td> <td>GROUND</td> </tr> <tr> <td>87</td> <td>OR-F</td> <td>GROUND</td> </tr> <tr> <td>30</td> <td>505</td> <td>12 VOLT TO OVERHEAD LAMPS</td> </tr> </tbody> </table>	TABLE OF CONTENTS			CAVITY	CIRCUIT	FUNCTION	86	503	12 VOLT SUPPLY	85	504L/504R	GROUND	87	OR-F	GROUND	30	505	12 VOLT TO OVERHEAD LAMPS	 <p><b>CONNECTOR 10 MAIN CAB TO DOOR HARNESS (LHS)</b></p> <table border="1"> <thead> <tr> <th colspan="3">TABLE OF CONTENTS</th> </tr> <tr> <th>CAVITY</th> <th>CIRCUIT</th> <th>FUNCTION</th> </tr> </thead> <tbody> <tr> <td>C</td> <td>OC</td> <td>GROUND</td> </tr> </tbody> </table>	TABLE OF CONTENTS			CAVITY	CIRCUIT	FUNCTION	C	OC	GROUND																		
TABLE OF CONTENTS																																														
CAVITY	CIRCUIT	FUNCTION																																												
86	503	12 VOLT SUPPLY																																												
85	504L/504R	GROUND																																												
87	OR-F	GROUND																																												
30	505	12 VOLT TO OVERHEAD LAMPS																																												
TABLE OF CONTENTS																																														
CAVITY	CIRCUIT	FUNCTION																																												
C	OC	GROUND																																												
 <p><b>CONNECTOR 5 OVERHEAD CAB LAMP</b></p> <table border="1"> <thead> <tr> <th colspan="3">TABLE OF CONTENTS</th> </tr> <tr> <th>CAVITY</th> <th>CIRCUIT</th> <th>FUNCTION</th> </tr> </thead> <tbody> <tr> <td>A</td> <td>131</td> <td>12 VOLT SUPPLY</td> </tr> <tr> <td>B</td> <td>505</td> <td>FROM DOOR LAMP RELAY</td> </tr> <tr> <td>C</td> <td>OC</td> <td>GROUND RHS DOOR</td> </tr> </tbody> </table>	TABLE OF CONTENTS			CAVITY	CIRCUIT	FUNCTION	A	131	12 VOLT SUPPLY	B	505	FROM DOOR LAMP RELAY	C	OC	GROUND RHS DOOR	 <p><b>CONNECTOR 11 SPLICE PACK OG</b></p> <table border="1"> <thead> <tr> <th colspan="3">TABLE OF CONTENTS</th> </tr> <tr> <th>CAVITY</th> <th>CIRCUIT</th> <th>FUNCTION</th> </tr> </thead> <tbody> <tr> <td>A</td> <td>OG</td> <td>GROUND</td> </tr> <tr> <td>E</td> <td>OC-L</td> <td>GROUND</td> </tr> </tbody> </table>	TABLE OF CONTENTS			CAVITY	CIRCUIT	FUNCTION	A	OG	GROUND	E	OC-L	GROUND																		
TABLE OF CONTENTS																																														
CAVITY	CIRCUIT	FUNCTION																																												
A	131	12 VOLT SUPPLY																																												
B	505	FROM DOOR LAMP RELAY																																												
C	OC	GROUND RHS DOOR																																												
TABLE OF CONTENTS																																														
CAVITY	CIRCUIT	FUNCTION																																												
A	OG	GROUND																																												
E	OC-L	GROUND																																												
 <p><b>CONNECTOR 6 OVERHEAD CAB LAMP</b></p> <table border="1"> <thead> <tr> <th colspan="3">TABLE OF CONTENTS</th> </tr> <tr> <th>CAVITY</th> <th>CIRCUIT</th> <th>FUNCTION</th> </tr> </thead> <tbody> <tr> <td>A</td> <td>131</td> <td>12 VOLT SUPPLY</td> </tr> <tr> <td>B</td> <td>505</td> <td>FROM DOOR LAMP RELAY</td> </tr> <tr> <td>C</td> <td>OC</td> <td>GROUND</td> </tr> </tbody> </table>	TABLE OF CONTENTS			CAVITY	CIRCUIT	FUNCTION	A	131	12 VOLT SUPPLY	B	505	FROM DOOR LAMP RELAY	C	OC	GROUND	 <p><b>CONNECTOR 12 MAIN CAB HARNESS TO DOOR HARNESS RHS</b></p> <table border="1"> <thead> <tr> <th colspan="3">TABLE OF CONTENTS</th> </tr> <tr> <th>CAVITY</th> <th>CIRCUIT</th> <th>FUNCTION</th> </tr> </thead> <tbody> <tr> <td>C</td> <td>OC-R</td> <td>GROUND</td> </tr> <tr> <td>D</td> <td>712</td> <td>GROUND CONTROL FEED</td> </tr> <tr> <td>E</td> <td>713R</td> <td>CONTROL SUPPLY</td> </tr> <tr> <td>F</td> <td>714R</td> <td>CONTROL SUPPLY</td> </tr> </tbody> </table>  <p><b>CONNECTOR 13 SPLICE PACK O</b></p> <table border="1"> <thead> <tr> <th colspan="3">TABLE OF CONTENTS</th> </tr> <tr> <th>CAVITY</th> <th>CIRCUIT</th> <th>FUNCTION</th> </tr> </thead> <tbody> <tr> <td>A</td> <td>O</td> <td>GROUND</td> </tr> <tr> <td>B</td> <td>OC-R</td> <td>GROUND</td> </tr> </tbody> </table>	TABLE OF CONTENTS			CAVITY	CIRCUIT	FUNCTION	C	OC-R	GROUND	D	712	GROUND CONTROL FEED	E	713R	CONTROL SUPPLY	F	714R	CONTROL SUPPLY	TABLE OF CONTENTS			CAVITY	CIRCUIT	FUNCTION	A	O	GROUND	B	OC-R	GROUND
TABLE OF CONTENTS																																														
CAVITY	CIRCUIT	FUNCTION																																												
A	131	12 VOLT SUPPLY																																												
B	505	FROM DOOR LAMP RELAY																																												
C	OC	GROUND																																												
TABLE OF CONTENTS																																														
CAVITY	CIRCUIT	FUNCTION																																												
C	OC-R	GROUND																																												
D	712	GROUND CONTROL FEED																																												
E	713R	CONTROL SUPPLY																																												
F	714R	CONTROL SUPPLY																																												
TABLE OF CONTENTS																																														
CAVITY	CIRCUIT	FUNCTION																																												
A	O	GROUND																																												
B	OC-R	GROUND																																												




CHANGE HISTORY
DESCRIPTION
CORRECTED MICRO-RELAY DETAIL




V990158



V390062



V830014



V390311

